



# Image Processing Report



## ▼ GUI & Functions

```

function varargout = gui(varargin)
% Begin initialization code - DO NOT EDIT
gui_Singleton = 1;
gui_State = struct('gui_Name',    mfilename, ...
                  'gui_Singleton', gui_Singleton, ...
                  'gui_OpeningFcn', @gui_OpeningFcn, ...
                  'gui_OutputFcn', @gui_OutputFcn, ...
                  'gui_LayoutFcn', [] , ...
                  'gui_Callback', []);
if nargin && ischar(varargin{1})
    gui_State.gui_Callback = str2func(varargin{1});
end

if nargout
    [varargout{1:nargout}] = gui_mainfcn(gui_State, varargin{:});
else
    gui_mainfcn(gui_State, varargin{:});
end

```

### 1. **function varargout = gui(varargin)**

This defines the main function of the GUI.

- **varargout** is a variable output argument, meaning it can return multiple values (used when the number of outputs varies).
- **varargin** is a variable input argument, meaning the function can accept a variable number of inputs.

### 4. **gui\_Singleton = 1;**

This line sets a flag **gui\_Singleton** to 1. The purpose of this is to ensure that only a single instance of the GUI can be opened at a time. If **gui\_Singleton** is set to 1, the GUI will be a singleton.

### 5. **gui\_State = struct('gui\_Name', mfilename, ...**

This creates a structure **gui\_State** that holds information about the GUI.

- **gui\_Name**: This stores the name of the current file, obtained using **mfilename**. It is typically used for referencing the GUI's name.

## 5. `'gui_Singleton', gui_Singleton, ...`

This assigns the value of `gui_Singleton` (1, as set earlier) to the `gui_Singleton` field of the `gui_State` structure. This indicates that the GUI should be a singleton.

## 6. `'gui_OpeningFcn', @gui_OpeningFcn, ...`

This sets the `gui_OpeningFcn` field of `gui_State` to a function handle `@gui_OpeningFcn`. This refers to the function that is called when the GUI is first opened.

## 7. `'gui_OutputFcn', @gui_OutputFcn, ...`

This assigns the `gui_OutputFcn` field of `gui_State` to the function handle `@gui_OutputFcn`. This refers to the function that is responsible for returning output values from the GUI.

## 8. `'gui_LayoutFcn', [], ...`

This sets the `gui_LayoutFcn` field to an empty array. This is typically used for specifying the layout function for the GUI, but in this case, no layout function is specified.

## 9. `'gui_Callback', [];`

This sets the `gui_Callback` field to an empty array. This field can store a function handle that will be called when a certain event or callback happens (like a button press), but it is not used in this code.

## 10. `if nargin && ischar(varargin{1})`

This checks if there is at least one input argument ( `nargin` ) and if the first argument ( `varargin{1}` ) is a string ( `ischar` ). If these conditions are met, it proceeds with the code inside the `if` block.

## 11. `gui_State.gui_Callback = str2func(varargin{1});`

If the condition in the previous line is true, this line sets the `gui_Callback` field of the `gui_State` structure to a function handle created from the string stored in `varargin{1}` using `str2func`. This allows dynamic function assignment.

## 12. `if nargout`

This checks if there are any output arguments ( `nargout` ). If the number of output arguments is greater than zero, the code inside the `if` block is executed.

### 13. `[varargout{1:nargout}] = gui_mainfcn(gui_State, varargin{:});`

If the number of output arguments is greater than zero, this line calls the main function of the GUI, `gui_mainfcn`, passing the `gui_State` structure and the input arguments (`varargin`). It returns the outputs in `varargout`.

### 14. `else`

This marks the start of the `else` block that will be executed if `nargout` is zero (i.e., no output arguments).

### 15. `gui_mainfcn(gui_State, varargin{:});`

If there are no output arguments, this line simply calls the `gui_mainfcn` without returning anything. It just executes the main GUI function.

```
% --- Executes just before gui is made visible.
function gui_OpeningFcn(hObject, ~, handles, varargin)
% Initialize filter options
set(handles.popupmenu1, 'String', {'Correlation', 'Weighted'});
set(handles.popupmenu1, 'Value', 1);
set(handles.edit1, 'String', '0');
set(handles.edit2, 'String', '255');

% Initialize default kernel
handles.filterKernel = ones(3,3)/9;
if isfield(handles, 'uitable3')
    set(handles.uitable3, 'Data', num2cell(handles.filterKernel));
end

% Initialize non-linear filter options
nonLinearFilters = {
    'Min Filter',
    'Max Filter',
    'Mean Filter',
    'Midpoint Filter',
    'Median Filter'
};
set(handles.popupmenu3, 'String', nonLinearFilters);
```

```

set(handles.popupmenu3, 'Value', 1); % Default to first option

noiseFilters = {
    'Min Filter',
    'Max Filter',
    'Mean Filter',
    'Median Filter',
    'Midpoint Filter'
};

set(handles.popupmenu6, 'String', noiseFilters); % Assuming popupmenu3
set(handles.popupmenu6, 'Value', 1); % Default to first option

set(handles.edit7, 'String', '0.05'); % Salt & Pepper PS
set(handles.edit8, 'String', '0.05'); % Salt & Pepper PP
set(handles.edit9, 'String', '10'); % Uniform a
set(handles.edit10, 'String', '200'); % Uniform b
set(handles.edit11, 'String', '10'); % Uniform P
set(handles.edit12, 'String', '10'); % Gaussian seg
set(handles.edit13, 'String', '10'); % Gaussian m
set(handles.edit14, 'String', '10'); % Gaussian P
set(handles.edit17, 'String', '10'); % Exponential a
set(handles.edit18, 'String', '200'); % Exponential b
set(handles.edit19, 'String', '240'); % Rayleigh b
set(handles.edit20, 'String', '240'); % Rayleigh a
set(handles.edit21, 'String', '0'); % Gamma a
set(handles.edit22, 'String', '255'); % Gamma b
% Initialize image fields
handles.currentImage = [];
handles.filteredImage = [];
% Initialize point operations menu
pointOperations = {'Point Detection', 'Point Sharpening'};
set(handles.popupmenu7, 'String', pointOperations);
set(handles.popupmenu7, 'Value', 1); % Default to Point Detection
% Initialize line operations menu
lineOperations = {
    'Line Detection (Sobel)',
    'Line Detection (Roberts)',

```

```

    'Line Sharpening'
};
set(handles.popupmenu8, 'String', lineOperations);
set(handles.popupmenu8, 'Value', 1); % Default to Sobel

% Initialize direction buttons as invisible
set([handles.pushbutton31, handles.pushbutton32, handles.pushbutton33,
set(handles.pushbutton31, 'String', 'H');
set(handles.pushbutton32, 'String', 'V');
set(handles.pushbutton33, 'String', 'DL');
set(handles.pushbutton34, 'String', 'DR');
% Initialize transformation parameters
handles.transformationParams = struct(...
    'gammaValue', 1.0, ...    % Default gamma value
    'logConstant', 1.0, ...   % Constant for log transformation
    'negativeActive', false ... % Flag for negative transformation
);

% Set default gamma value in the edit box
set(handles.edit23, 'String', num2str(handles.transformationParams.gamm
% Initialize frequency domain filter parameters
set(handles.edit26, 'String', '5'); % D0 cutoff frequency
set(handles.edit27, 'String', '1'); % Butterworth order

% Initialize filter type popupmenu
filterTypes = {
    'Ideal Low Pass',
    'Ideal High Pass',
    'Butterworth Low Pass',
    'Butterworth High Pass',
    'Gaussian Low Pass',
    'Gaussian High Pass'
};
set(handles.popupmenu10, 'String', filterTypes);
set(handles.popupmenu10, 'Value', 1); % Default to Ideal Low Pass
% Initialize brightness parameters
set(handles.edit28, 'String', '10'); % Default brightness adjustment value
handles.brightnessValue = 10;

```

```
% Choose default command line output
handles.output = hObject;
handles.currentImage = [];
handles.noisyImage = [];
handles.frequencyFilteredImage = [];
% Initialize Fourier transform variables
handles.fourierData = []; % Will store Fourier transform data
handles.reconstructedImage = []; % Will store reconstructed image
% Initialize conversion parameters
set(handles.edit29, 'String', '127'); % Default binary threshold
set(handles.edit30, 'String', '1'); % Default grayscale method (1-5)
% Initialize other variables
handles.currentImage = [];
handles.processedImage = [];
% Initialize default values for Fourier display
handles.fourierDisplayMode = 'magnitude'; % Can be 'magnitude' or 'phas
% Initialize kernel size (default 3x3)
handles.kernelSize = 3;

% Update handles structure
guidata(hObject, handles);
```

## ◆ Function Header

```
function gui_OpeningFcn(hObject, ~, handles, varargin)
```

This is the GUI Opening Function. It's called just before the GUI window becomes visible.

- `hObject` : handle to the GUI figure
- `handles` : structure containing handles to GUI components
- `varargin` : any additional parameters passed when launching the GUI

## 1. Correlation & Weighted Filter Initialization

```
set(handles.popupmenu1, 'String', {'Correlation', 'Weighted'});
set(handles.popupmenu1, 'Value', 1);
```

```
set(handles.edit1, 'String', '0');  
set(handles.edit2, 'String', '255');
```

- Initializes the first popup menu ( `popupmenu1` ) with filter options.
- Default selected value is **Correlation**.
- `edit1` and `edit2` are set to grayscale intensity range (0–255).

## 2. Linear Filter Kernel Initialization

```
handles.filterKernel = ones(3,3)/9;  
if isfield(handles, 'uitable3')  
    set(handles.uitable3, 'Data', num2cell(handles.filterKernel));  
end
```

- Sets a **default 3×3 average kernel** (used for linear filtering).
- Displays it in `uitable3` (if the table exists).

## 3. Non-Linear Filter Options

```
nonLinearFilters = {  
    'Min Filter',  
    'Max Filter',  
    'Mean Filter',  
    'Midpoint Filter',  
    'Median Filter'  
};  
set(handles.popupmenu3, 'String', nonLinearFilters);  
set(handles.popupmenu3, 'Value', 1);
```

- Initializes **non-linear filter options** (like Min, Max, Median).
- Sets default to **Min Filter** in `popupmenu3`.

## 4. Noise Filter Options



```
noiseFilters = {
    'Min Filter',
    'Max Filter',
    'Mean Filter',
    'Median Filter',
    'Midpoint Filter'
};
set(handles.popupmenu6, 'String', noiseFilters);
set(handles.popupmenu6, 'Value', 1);
```

- Similar to non-linear filters, possibly reused for **denoising filters**.
- `popupmenu6` is set to **Min Filter** by default.

## 5. Noise Parameters (Salt & Pepper, Uniform, Gaussian, etc.)

```
set(handles.edit7, 'String', '0.05'); % Salt & Pepper PS
set(handles.edit8, 'String', '0.05'); % Salt & Pepper PP
set(handles.edit9, 'String', '10'); % Uniform a
set(handles.edit10, 'String', '200'); % Uniform b
set(handles.edit11, 'String', '10'); % Uniform P
set(handles.edit12, 'String', '10'); % Gaussian seg
set(handles.edit13, 'String', '10'); % Gaussian m
set(handles.edit14, 'String', '10'); % Gaussian P
set(handles.edit17, 'String', '10'); % Exponential a
set(handles.edit18, 'String', '200'); % Exponential b
set(handles.edit19, 'String', '240'); % Rayleigh b
set(handles.edit20, 'String', '240'); % Rayleigh a
set(handles.edit21, 'String', '0'); % Gamma a
set(handles.edit22, 'String', '255'); % Gamma b
```

- Initializes **parameters for adding synthetic noise**.
- Each pair of edits corresponds to a specific distribution type.

## 6. Image Placeholders

```
handles.currentImage = [];  
handles.filteredImage = [];
```

- Prepares fields to store the **original and filtered images**.

## 7. Point Operations Menu

```
pointOperations = {'Point Detection', 'Point Sharpening'};  
set(handles.popupmenu7, 'String', pointOperations);  
set(handles.popupmenu7, 'Value', 1);
```

- Provides a menu for **point-based image operations**.

## 8. Line Operations Menu

```
lineOperations = {  
    'Line Detection (Sobel)',  
    'Line Detection (Roberts)',  
    'Line Sharpening'  
};  
set(handles.popupmenu8, 'String', lineOperations);  
set(handles.popupmenu8, 'Value', 1);
```

- Provides **line detection/sharpening methods**.
- Default is **Sobel** operator.

## 9. Direction Buttons (for directional filtering)

```
set([handles.pushbutton31, handles.pushbutton32, handles.pushbutton33, handles.pushbutton34], 'Visible', 'on', 'Enable', 'on');  
set(handles.pushbutton31, 'String', 'H');  
set(handles.pushbutton32, 'String', 'V');  
set(handles.pushbutton33, 'String', 'DL');  
set(handles.pushbutton34, 'String', 'DR');
```

- Enables buttons for **direction selection**:
    - H: Horizontal
    - V: Vertical
    - DL: Diagonal Left
    - DR: Diagonal Right
- 

## 10. Transformation Parameters

```
handles.transformationParams = struct(...
    'gammaValue', 1.0, ...
    'logConstant', 1.0, ...
    'negativeActive', false ...
);
set(handles.edit23, 'String', num2str(handles.transformationParams.gammaValue));
```

- Initializes default parameters for image transformations like:
    - Gamma correction
    - Log transformation
    - Negative transformation
- 

## 11. Frequency Domain Filters

```
set(handles.edit26, 'String', '5'); % D0
set(handles.edit27, 'String', '1'); % Butterworth order

filterTypes = {
    'Ideal Low Pass',
    'Ideal High Pass',
    'Butterworth Low Pass',
    'Butterworth High Pass',
    'Gaussian Low Pass',
    'Gaussian High Pass'
};
```

```
set(handles.popupmenu10, 'String', filterTypes);  
set(handles.popupmenu10, 'Value', 1);
```

- Initializes **frequency domain filter** parameters:
  - Cutoff frequency `D0`
  - Filter type selector ( `popupmenu10` )

## 12. Brightness Settings

```
set(handles.edit28, 'String', '10');  
handles.brightnessValue = 10;
```

- Sets default **brightness adjustment** value to 10.

## 13. More Image Placeholders

```
handles.output = hObject;  
handles.currentImage = [];  
handles.noisyImage = [];  
handles.frequencyFilteredImage = [];
```

- Additional fields to hold different image states.

## 14. Fourier Variables

```
handles.fourierData = [];  
handles.reconstructedImage = [];
```

- Placeholder for **Fourier Transform result** and **inverse** image.

## 15. Image Conversion Parameters

```
set(handles.edit29, 'String', '127'); % Threshold for binary conversion  
set(handles.edit30, 'String', '1'); % Grayscale conversion method (1 to
```

5)

- For converting the image to binary or grayscale using specified methods.

## 16. Final Setup

```
handles.currentImage = [];  
handles.processedImage = [];  
handles.fourierDisplayMode = 'magnitude'; % Default Fourier display  
handles.kernelSize = 3; % Default filter kernel size
```

## 17. Update **handles** Structure

```
guidata(hObject, handles);
```

- Saves the modified **handles** back into the GUI's internal data.
- Necessary for the changes to persist.

## Summary Table

Group	Purpose
Filter Menus	Correlation, Weighted, Non-linear filters
Noise Inputs	Salt & Pepper, Gaussian, Rayleigh, etc.
Line/Point Menus	Point/Line detection & sharpening
Transformation	Gamma, Log, Negative settings
Fourier Filters	Ideal, Butterworth, Gaussian
Direction Buttons	Horizontal, Vertical, Diagonals
Image Data	Stores original, noisy, processed images
Display & Conversion	Brightness, threshold, display modes

## ▼ Linear Filters

```

% --- Outputs from this function are returned to the command line.
function varargout = gui\_OutputFcn(hObject, eventdata, handles)
varargout{1} = handles.output;

% --- Helper function to validate numeric input
function valid = validateInput(handle, minVal, maxVal, isInteger)
str = get(handle, 'String');
num = str2double(str);
if isnan(num) || num < minVal || num > maxVal
    valid = false;
    set(handle, 'String', '');
    errordlg(sprintf('Please enter a number between %.2f and %.2f', minVal, maxVal));
else
    if isInteger
        num = round(num);
        set(handle, 'String', num2str(num));
    end
    valid = true;
end

% --- Executes on selection change in popupmenu1.
function popupmenu1_Callback(hObject, eventdata, handles)
set(handles.uitable3, 'Data', handles.filterKernel);

% --- Executes during object creation, after setting all properties.
function popupmenu1_CreateFcn(hObject, eventdata, handles)
if ispc && isequal(get(hObject,'BackgroundColor'), get(0,'defaultUicontrolBackgroundColor'))
set(hObject,'BackgroundColor','white');
end

% --- Executes on selection change in listbox1.
%function listbox1_Callback(hObject, eventdata, handles)

% --- Executes during object creation, after setting all properties.
function listbox1_CreateFcn(hObject, eventdata, handles)
if ispc && isequal(get(hObject,'BackgroundColor'), get(0,'defaultUicontrolBackgroundColor'))
set(hObject,'BackgroundColor','white');
end

```

```

% --- Executes on button press in apply.
function apply_Callback(hObject, eventdata, handles)
% Check if image exists
if ~isfield(handles, 'currentImage') || isempty(handles.currentImage)
    error('Please load an image first using the "Load Image" button.', 'No Im
return;
end

try
% Initialize default kernel if not exists
if ~isfield(handles, 'filterKernel')
    handles.filterKernel = ones(3,3)/9;
end

...

% Get selected filter type
filterTypes = get(handles.popupmenu1, 'String');
selectedFilter = filterTypes{get(handles.popupmenu1, 'Value')};

% Get kernel data safely
if isfield(handles, 'uitable3')
    kernelData = get(handles.uitable3, 'Data');
    if iscell(kernelData)
        % Convert cell to matrix, handling empty/non-numeric values
        kernelData = cellfun(@(x) ifelse(isempty(x)||~isnumeric(x),0,x), kernel
        handles.filterKernel = cell2mat(kernelData);
    else
        handles.filterKernel = kernelData;
    end
end

% Use filtered image if it exists, otherwise use original
if isfield(handles, 'filteredImage') && ~isempty(handles.filteredImage)
    img = handles.filteredImage;
else
    img = handles.currentImage;
end

```

```

% Process image
if size(img, 3) == 3
    img = rgb2gray(img);
end

% Apply selected filter
switch selectedFilter
    case 'Correlation'
        filteredImg = imfilter(double(img), handles.filterKernel, 'corr', 'same');
    case 'Weighted'
        % Normalize kernel
        normalizedKernel = handles.filterKernel / sum(handles.filterKernel(:));
        filteredImg = imfilter(double(img), normalizedKernel, 'conv', 'same');
    end

% Always show original in axes1
axes(handles.axes1);
imshow(handles.currentImage);
title('Original Image');

% Show filtered result in axes2
axes(handles.axes2);
imshow(filteredImg, []);
title([selectedFilter ' Result']);

% Store for next operation
handles.filteredImage = filteredImg;
guidata(hObject, handles);
...

catch e
    errordlg(['Error applying filter: ' e.message], 'Filter Error');
end

% Helper function
function y = ifelse(condition, trueval, falseval)
if condition

```



```

y = trueval;
else
y = falseval;
end

```

## ◆ 1. GUI Output Function

This function returns the main output of the GUI (typically the `handles.output`) to the command line.

```

function varargout = gui_OutputFcn(hObject, eventdata, handles)
    varargout{1} = handles.output;
end

```

## ◆ 2. Validation Helper Function

Validates the input from a UI text box (used when entering numeric values in a kernel, for example).

```

function valid = validateInput(handle, minVal, maxVal, isInteger)
    str = get(handle, 'String');           % Get the input as a string
    num = str2double(str);                 % Convert to number
    if isnan(num) || num < minVal || num > maxVal
        valid = false;
        set(handle, 'String', '');
        errorDlg(sprintf('Please enter a number between %.2f and %.2f', minVal, maxVal), 'Invalid Input');
    else
        if isInteger                        % Round if required
            num = round(num);
            set(handle, 'String', num2str(num));
        end
        valid = true;
    end
end

```

## ◆ 3. Dropdown (Popup Menu) Logic

Used to choose the filter type (Correlation or Weighted). Also sets the kernel data in the UI table.

```
function popupmenu1_Callback(hObject, eventdata, handles)
    set(handles.uitable3, 'Data', handles.filterKernel);
end
```

Creates the popup menu (dropdown list) with a white background.

```
function popupmenu1_CreateFcn(hObject, eventdata, handles)
    if ispc && isequal(get(hObject,'BackgroundColor'), get(0,'defaultUicontrolBackgroundColor'))
        set(hObject,'BackgroundColor','white');
    end
end
```

## ◆ 5. Apply Filter Button Logic

This is where most of the filtering logic is implemented. It gets triggered when the **"Apply"** button is clicked.

### ✓ General Steps:

1. Check if an image is loaded.
2. Get the selected filter (Correlation or Weighted).
3. Get and validate the kernel matrix from `uitable3`.
4. Convert image to grayscale if needed.
5. Apply the selected filter.
6. Display original and filtered images.

### ◆ 1. Check if an image is loaded

```
if ~isfield(handles, 'currentImage') || isempty(handles.currentImage)
    errorDlg('Please load an image first using the "Load Image" button.',
        'No Image Found');
```

```
return;  
end
```

### ✓ What this does:

- Checks if the `handles` structure has a field called `currentImage` **and** that it's not empty.
- If not, it shows an error dialog to the user saying **"No Image Found"**.
- `return` exits the callback function early to prevent errors (you can't filter a nonexistent image).

## ◆ 2. Create a default filter kernel if one doesn't exist

```
if ~isfield(handles, 'filterKernel')  
    handles.filterKernel = ones(3,3)/9;  
end
```

### ✓ What this does:

- Checks if a field called `filterKernel` exists in the `handles` structure.
- If not, it creates a **3×3 average kernel** (each value is `1/9`).
- This kernel is often used for **blurring or smoothing**.

## ◆ 3. Get the selected filter name from the popup menu

```
filterTypes = get(handles.popupmenu1, 'String');  
selectedFilter = filterTypes{get(handles.popupmenu1, 'Value')};
```

### ✓ What this does:

- Retrieves the list of available filters from `popupmenu1` (like `'Correlation'`, `'Weighted'`, etc.).
- Gets the currently selected filter using `get(..., 'Value')`.
- Stores it in the variable `selectedFilter`.

For example:

If the dropdown has: `{'Correlation', 'Weighted'}` and the user chooses the second one, `selectedFilter` will be `'Weighted'`.

#### ◆ 4. Read the kernel matrix from the UI table ( `uitable3` )

```
if isfield(handles, 'uitable3')
    kernelData = get(handles.uitable3, 'Data');
```

- This checks if the `uitable3` field exists (i.e., the GUI contains a table for kernel editing).
- Retrieves the **data inside the table**, which could be a cell array or numeric matrix.

#### ◆ 4.a. If kernel is a cell (like editable table), convert it

```
if iscell(kernelData)
    kernelData = cellfun(@(x) ifelse isempty(x) || ~isnumeric(x), 0, x), kernelData, 'UniformOutput', false);
    handles.filterKernel = cell2mat(kernelData);
```

#### ✓ What this does:

- `cellfun` goes through each element of the table.
- If the cell is **empty or not numeric**, it's replaced with `0`.
- Otherwise, it keeps the number.
- The result is converted into a numeric matrix using `cell2mat`.

This is important because `uitable` allows any kind of input (strings, empty), but filters need a pure **numeric matrix**.

#### ◆ 4.b. If it's already a numeric matrix

```
else
    handles.filterKernel = kernelData;
end
```

- If the table data was already numeric, no conversion is needed.

---

## ◆ 5. Choose which image to apply the filter to

```
if isfield(handles, 'filteredImage') && ~isempty(handles.filteredImage)
    img = handles.filteredImage;
else
    img = handles.currentImage;
end
```

### ✓ What this does:

- If there's a previously filtered image ( `handles.filteredImage` ), use that as the input for the new filter.
- Otherwise, use the original image ( `handles.currentImage` ).
- This allows **chaining multiple filters** together.

---

## ◆ 6. Convert color image to grayscale (if necessary)

```
if size(img, 3) == 3
    img = rgb2gray(img);
end
```

### ✓ What this does:

- Checks if the image has 3 color channels (RGB).
- If so, converts it to **grayscale**, because most basic filters work on single-channel images.
- `rgb2gray()` reduces an RGB image to shades of gray using a weighted sum of R, G, and B.

---

### ✓ Summary of Workflow:

Step	Purpose
1	Check if the image is loaded
2	Set a default kernel if none is provided
3	Read the selected filter name

4	Safely read and clean the kernel from the UI table
5	Use the latest filtered image (if exists), otherwise use original
6	Convert image to grayscale if it's colored

## Filter Type 1: Correlation

```
case 'Correlation'
    filteredImg = imfilter(double(img), handles.filterKernel, 'corr', 'same');
```

- `imfilter` applies the **correlation operation** using the provided kernel.
- `'corr'` means no flipping of kernel (standard correlation).
- `'same'` keeps output size equal to input size.

## Filter Type 2: Weighted Average (Normalized Convolution)

```
case 'Weighted'
    normalizedKernel = handles.filterKernel / sum(handles.filterKernel(:));
    filteredImg = imfilter(double(img), normalizedKernel, 'conv', 'same');
```

- Kernel is **normalized** (each element is divided by the total sum).
- `'conv'` means convolution (kernel is flipped).
- Often used for **blurring/smoothing** operations.

## ◆ Display and Store the Output

```
% Display original image
axes(handles.axes1);
imshow(handles.currentImage);
title('Original Image');

% Display filtered image
axes(handles.axes2);
imshow(filteredImg, []);
title([selectedFilter ' Result']);
```

```
% Save filtered image to handles
handles.filteredImage = filteredImg;
guidata(hObject, handles);
```

## ◆ 6. Helper Function - ifelse

Simplified version of ternary logic used during kernel value checks.

### **MATLAB doesn't have a built-in ternary operator**

That's why this function is created manually to fill that role.

```
function y = ifelse(condition, trueval, falseval)
    if condition
        y = trueval;
    else
        y = falseval;
    end
end
```

## ✓ Summary by Filter:

Filter Type	Logic Used	Notes
<b>Correlation</b>	<code>imfilter(..., 'corr', 'same')</code> using raw kernel	Used for pattern detection, edge-like operations
<b>Weighted</b>	Normalized kernel + <code>imfilter(..., 'conv', 'same')</code>	Used for smoothing, blurring

```
% --- Executes when entered data in editable cell(s) in uitable3.
function uitable3_CellEditCallback(hObject, eventdata, handles)
try
    newData = get(hObject, 'Data');
    % Convert from cell if needed
    if iscell(newData)
        newData = cell2mat(newData);
    end
    handles.filterKernel = newData;
    guidata(hObject, handles);
```

```

catch e
    errorDlg(['Invalid kernel value: ' e.message], 'Input Error');
end

```

## ◆ Purpose:

This function runs **whenever the user edits any cell** inside the GUI table component `uitable3`, which is used to represent the filter kernel (like for correlation or weighted filtering).

## ◆ Detailed Line-by-Line Explanation:

Line	Explanation
<code>function uitable3_CellEditCallback(...)</code>	Declares a callback function triggered when a cell in <code>uitable3</code> is edited.
<code>newData = get(hObject, 'Data');</code>	Retrieves the updated data from the table. The data is likely a <b>cell array</b> if edited manually.
<code>if iscell(newData)</code>	Checks if the retrieved data is a <b>cell array</b> (which it is when you edit uitable directly).
<code>newData = cell2mat(newData);</code>	Converts the cell array to a numeric matrix, needed for matrix operations like filtering.
<code>handles.filterKernel = newData;</code>	Stores the converted kernel into the global <code>handles</code> structure under the field <code>filterKernel</code> . This is essential to apply the custom kernel later.
<code>guidata(hObject, handles);</code>	Updates the <code>handles</code> structure in the GUI so the new kernel value is accessible by other callbacks (e.g., apply filter).
<code>catch e ...</code>	If anything fails (like a non-numeric cell), shows an error dialog box with a custom error message.

## 🧩 Filter Group:

This function belongs to the **Linear Filters Group**:

Filter Group	Components
<b>Linear Filters</b>	- Correlation Filter- Weighted Filter



#### Related Components

- `uitable3` for kernel input- `popupmenu1` for selecting filter-  
`apply_Callback` for execution

## ▼ **3 Non-Linear Filters (Spatial Domain)** implementation

### Fixed 3x3 Non-Linear Filter

 `pushbutton30_Callback` (always uses 3×3)

```
% --- Executes on button press in pushbutton30.
function pushbutton30_Callback(hObject, eventdata, handles)
    if ~isfield(handles, 'currentImage') || isempty(handles.currentImage)
        errorDlg('Please load an image first.', 'No Image Found');
        return;
    end

    % Get selected filter from popupmenu3
    val = get(handles.popupmenu3, 'Value');

    % Use filtered image if it exists, otherwise original
    if isfield(handles, 'filteredImage') && ~isempty(handles.filteredImage)
        img = handles.filteredImage;
    else
        img = handles.currentImage;
    end

    % Convert to grayscale if RGB
    if size(img, 3) == 3
        img = rgb2gray(img);
    end

    switch val
        case 1 % Min filter
            imgOut = ordfilt2(img, 1, ones(3));
        case 2 % Max filter
            imgOut = ordfilt2(img, 9, ones(3));
```

```

    case 3 % Median filter
        imgOut = medfilt2(img, [3 3]);
    case 4 % Mean filter
        h = fspecial('average', [3 3]);
        imgOut = imfilter(img, h);
    case 5 % Midpoint filter
        minImg = ordfilt2(img, 1, ones(3));
        maxImg = ordfilt2(img, 9, ones(3));
        imgOut = (double(minImg) + double(maxImg)) / 2;
        imgOut = uint8(imgOut);
    otherwise
        errordlg('Invalid filter selection.');
```

return;

end

axes(handles.axes2);  
 imshow(imgOut);  
 title('Filtered Image');

handles.filteredImage = imgOut;  
 guidata(hObject, handles);

catch e  
 errordlg(['Error applying ' selectedFilter ': ' e.message], 'Filter Error');

end

This function runs when the user clicks the button labeled (likely) "Apply Fixed Filter".

```

matlab
Copy code
% --- Executes on button press in pushbutton30.
function pushbutton30_Callback(hObject, eventdata, handles)
```

👉 This is the function header. It's automatically triggered when `pushbutton30` is pressed.

- `hObject` : the handle to the button object.
- `eventdata` : not used here, but stores event data.
- `handles` : structure storing GUI data and handles.

## 🔍 Check for Image Availability

```
matlab
Copy code
% Check if image exists
if ~isfield(handles, 'currentImage') || isempty(handles.currentImage)
    errorDlg('Please load an image first.', 'No Image Found');
    return;
end
```

✓ Ensures that an image is loaded before proceeding.

- If `handles.currentImage` doesn't exist or is empty, an error dialog appears and the function exits.

## 🧠 Get Selected Filter from Dropdown

```
matlab
Copy code
% Get selected filter
filterList = get(handles.popupmenu3, 'String');
selectedFilter = filterList{get(handles.popupmenu3, 'Value')};
```

💡 This part reads the filter name chosen in `popupmenu3`, which contains options like:

- Min Filter
- Max Filter
- Mean Filter

- Median Filter
- Midpoint Filter

It does this in two steps:

- `get(..., 'String')` retrieves the **cell array** of all dropdown entries.
- `get(..., 'Value')` retrieves the **index** of the currently selected item.
- Combining them gives the selected string (e.g., `'Median Filter'` ).



## Get Current Image (Filtered or Original)

```
matlab
Copy code
try
    % Use filtered image if it exists, otherwise use original
    if isfield(handles, 'filteredImage') && ~isempty(handles.filteredImage)
        img = handles.filteredImage;
    else
        img = handles.currentImage;
    end
```

✓ Uses the **latest filtered image** if it exists, otherwise falls back to the original image ( `currentImage` ).



## Convert to Grayscale

```
matlab
Copy code
% Convert to grayscale if RGB
if size(img, 3) == 3
    img = rgb2gray(img);
end
```

✓ If the image is colored (RGB with 3 channels), convert it to grayscale.

Most spatial filters work on single-channel images.

## Apply the Selected Filter (Fixed 3×3)

matlab

Copy code

```
% Apply selected filter  
switch selectedFilter
```

### ◆ Min Filter

matlab

Copy code

```
case 'Min Filter'  
    filteredImg = ordfilt2(img, 1, ones(3,3));
```

● Takes the **minimum value** in a 3×3 neighborhood using `ordfilt2`.

### ◆ Max Filter

matlab

Copy code

```
case 'Max Filter'  
    filteredImg = ordfilt2(img, 9, ones(3,3));
```

● Takes the **maximum value** (9th in sorted list of 9 pixels).

### ◆ Mean Filter

matlab

Copy code

```
case 'Mean Filter'  
    h = fspecial('average', 3);  
    filteredImg = imfilter(img, h);
```

● Creates a 3×3 averaging kernel and applies it using `imfilter`.

## ◆ Midpoint Filter

matlab

Copy code

```
case 'Midpoint Filter'
    minImg = ordfilt2(img, 1, ones(3,3));
    maxImg = ordfilt2(img, 9, ones(3,3));
    filteredImg = (double(minImg) + double(maxImg)) / 2;
    filteredImg = uint8(filteredImg);
```

● Calculates the **average of min and max** values in the window.

- Converts to `double` to avoid overflow.
- Result is converted back to `uint8`.

## ◆ Median Filter

matlab

Copy code

```
case 'Median Filter'
    filteredImg = medfilt2(img, [3 3]);
```

● Uses `medfilt2` for **median filtering** in a 3×3 window.

## Display Images

matlab

Copy code

```
% Always show original in axes1
axes(handles.axes1);
imshow(handles.currentImage);
title('Original Image');
```

Displays the **original image** in `axes1`.

```
matlab
Copy code
% Show filtered result in axes2
axes(handles.axes2);
imshow(filteredImg);
title([selectedFilter ' Result']);
```

Displays the **filtered image** in `axes2` with a title showing the filter name.


## Save Filtered Image

```
matlab
Copy code
% Store for next operation
handles.filteredImage = filteredImg;
guidata(hObject, handles);
```

✓ Saves the filtered image in `handles` for further processing or chaining operations.

## Error Handling

```
matlab
Copy code
catch e
    errorDlg(['Error applying ' selectedFilter ': ' e.message], 'Filter Error');
end
```

 If an error occurs at any point in the `try` block, display an error dialog with the error message.



## Dropdown Initialization

 Inside `gui_OpeningFcn`

```

nonLinearFilters = {
    'Min Filter',
    'Max Filter',
    'Mean Filter',
    'Midpoint Filter',
    'Median Filter'
};
set(handles.popupmenu3, 'String', nonLinearFilters);
set(handles.popupmenu3, 'Value', 1); % Default

```

## UI Elements and Their Roles

### **popupmenu3**

- Dropdown menu for selecting the **non-linear filter**.
- Triggered When Filter Selection Changes
- The selected value is obtained using:


```
val = get(handles.popupmenu3, 'Value');
```

### **popupmenu3\_CreateFcn** – Initialization

```

% --- Executes during object creation, after setting all properties.
function popupmenu3_CreateFcn(hObject, eventdata, handles)
if ispc && isequal(get(hObject,'BackgroundColor'), get(0,'defaultUicontrolBackgroundColor'))
    set(hObject,'BackgroundColor','white');
end

```

 Sets the background color of the popup menu to white if the platform is Windows and the color is still default.

## Summary Table

Filter	Function	Kernel Size	Implementation Method
--------	----------	-------------	-----------------------



<b>Min</b>	<code>ordfilt2(img, 1, ...)</code>	User: <code>k×k</code> or Fixed: <code>3×3</code>	Non-linear Smoothing
<b>Max</b>	<code>ordfilt2(img, k^2, ...)</code>	User or Fixed ( $k^2=9$ )	Non-linear Edge Enhancing
<b>Median</b>	<code>medfilt2(img, [...])</code>	User or Fixed	Salt-and-pepper noise removal
<b>Mean</b>	<code>fspecial + imfilter</code>	User or Fixed	Smoothing / Averaging
<b>Midpoint</b>	Average of Min/Max	User or Fixed	Contrast Enhancement

## Histogram Processing

### 1. Histogram Comparison

#### `pushbutton8_Callback`

```
function pushbutton8_Callback(hObject, eventdata, handles)
```

◆ This function is called when the "Show Histogram Comparison" button is clicked.

#### Input Image Checks

```
if ~isfield(handles, 'currentImage') || isempty(handles.currentImage)
    errorlg('Please load an image first.', 'No Image Found');
    return;
end
```

✓ Confirms that an original image is loaded. If not, shows an error and exits.

```
if ~isfield(handles, 'filteredImage') || isempty(handles.filteredImage)
    errorlg('No processed image available. Please apply a filter first.', 'No Processed Image');
    return;
end
```

✓ Confirms that the user has already applied a filter (or processed the image). If not, exits.



## Setup & Display

```
originalImg = handles.currentImage;  
filteredImg = handles.filteredImage;  
  
hFig = figure('Name', 'Histogram Comparison', 'NumberTitle', 'off', 'Position', [100 100 1000 800]);
```



Creates a new figure window titled "Histogram Comparison" with a size of 1000×800 pixels.



## Original Image Display

```
subplot(2,2,1);  
if size(originalImg, 3) == 3  
    imshow(originalImg);  
    title('Original Color Image');
```



Shows the original image (color if 3 channels) in the top-left panel.

```
subplot(2,2,3);  
imhist(originalImg(:,:,1)); hold on;  
imhist(originalImg(:,:,2));  
imhist(originalImg(:,:,3)); hold off;  
title('Original RGB Histograms');  
legend('Red','Green','Blue');
```



Shows R, G, B channel histograms in the bottom-left panel.

```
else  
    imshow(originalImg);  
    title('Original Grayscale Image');  
  
    subplot(2,2,3);  
    imhist(originalImg);
```

```
title('Original Histogram');  
end
```

■ If the original is grayscale, just display its image and grayscale histogram.

---

## ■ Processed Image Display

```
subplot(2,2,2);  
imshow(filteredImg);  
title('Processed Image');
```

■ Shows the processed image (after filtering, equalization, or contrast stretching) in the top-right.

```
subplot(2,2,4);  
if size(filteredImg, 3) == 3  
    imhist(filteredImg(:,:,1)); hold on;  
    imhist(filteredImg(:,:,2));  
    imhist(filteredImg(:,:,3)); hold off;  
    title('Processed RGB Histograms');  
    legend('Red','Green','Blue');  
else  
    imhist(filteredImg);  
    title('Processed Histogram');  
end
```

■ Shows RGB or grayscale histograms of the processed image in the bottom-right.

---

## 📌 Add Title to the Whole Figure

```
annotation(hFig, 'textbox', [0.3 0.95 0.4 0.05], 'String', ...  
    'Histogram Comparison: Original vs Processed Image', ...  
    'EdgeColor', 'none', 'HorizontalAlignment', 'center', ...  
    'FontSize', 12, 'FontWeight', 'bold');
```

✎ Adds a main title above all subplots.

---

## Error Handling

```
catch e
    errordlg(['Error displaying histograms: ' e.message], 'Display Error');
end
```

 Catches and shows error if anything fails.

---

## 2. Histogram Equalization

### `pushbutton10_Callback`

```
function pushbutton10_Callback(hObject, eventdata, handles)
```

 Called when the "Histogram Equalization" button is pressed.

---

## Image Check

```
if ~isfield(handles, 'currentImage') || isempty(handles.currentImage)
    errordlg('Please load an image first.', 'No Image Found');
    return;
end
```


 Checks for an image before proceeding.

---

## Grayscale Conversion

```
img = handles.currentImage;


if size(img, 3) == 3
    img = rgb2gray(img);
end
```

 Converts to grayscale because `histeq` only works on 2D images.

---

## Histogram Equalization

```
equalizedImg = histeq(img);
```

 Stretches contrast using histogram equalization — makes dark/light areas more distinct.


## Display in GUI

```
axes(handles.axes2);  
imshow(equalizedImg);  
title('Histogram Equalization Result');
```

 Shows result in GUI ( `axes2` ).


## Compare Histograms in New Window

```
figure;  
subplot(2,1,1); imhist(img); title('Original Histogram');  
subplot(2,1,2); imhist(equalizedImg); title('Equalized Histogram');
```

 Visual comparison between the original and equalized histograms.

## Save Result

```
handles.filteredImage = equalizedImg;  
guidata(hObject, handles);
```


 Stores the processed image.

## Error Handling

```
catch e  
    errorDlg(['Error in histogram equalization: ' e.message], 'Processing E  
    rror');  
end
```

## 3. ✨ Contrast Stretching `pushbutton11_Callback`

```
function pushbutton11_Callback(hObject, eventdata, handles)
```

 Called when the user clicks the "Apply Contrast Stretching" button.



## Validation

```
if ~isfield(handles, 'currentImage') || isempty(handles.currentImage)
    errorDlg('Please load an image first.', 'No Image Found');
return;
end
```



## Read Min/Max from GUI Inputs

```
newMin = str2double(get(handles.edit1, 'String'));
newMax = str2double(get(handles.edit2, 'String'));

if isnan(newMin) || isnan(newMax) || newMin >= newMax
    errorDlg('Please enter valid min/max values (min < max).', 'Invalid Input');
return;
end
```

 Reads values from edit boxes and validates them.



## Convert and Stretch Contrast

```
img = handles.currentImage;

if size(img, 3) == 3
    img = rgb2gray(img);
end

minVal = double(min(img(:)));
maxVal = double(max(img(:)));

stretchedImg = (double(img) - minVal) .* ((newMax - newMin)/(maxVal -
```

```
minVal)) + newMin;  
stretchedImg = uint8(stretchedImg);
```

✓ This maps the pixel intensity range from `[minVal, maxVal]` to `[newMin, newMax]` using a linear formula.

## Display

```
axes(handles.axes2);  
imshow(stretchedImg);  
title(['Contrast Stretching [' num2str(newMin) ' to ' num2str(newMax)  
']']);
```

## Store and Save

```
handles.filteredImage = stretchedImg;  
guidata(hObject, handles);
```

## ✗ Error Handling

```
catch e  
    errordlg(['Error in contrast stretching: ' e.message], 'Processing Error');  
end
```

## `edit1_Callback` — Input for Min Value

```
function edit1_Callback(hObject, eventdata, handles)  
val = str2double(get(hObject, 'String'));  
if isnan(val) || val < 0 || val > 255  
    set(hObject, 'String', '0');  
    errordlg('Please enter a value between 0 and 255', 'Invalid Input');  
end
```

◆ Validates that the user typed a valid number in `edit1` for the **minimum** value.

### `edit2_Callback` — Input for Max Value

```
function edit2_Callback(hObject, eventdata, handles)
val = str2double(get(hObject, 'String'));
if isnan(val) || val < 0 || val > 255
    set(hObject, 'String', '255');
    errordlg('Please enter a value between 0 and 255', 'Invalid Input');
end
```

◆ Validates that the user typed a valid number in `edit2` for the **maximum** value.

### Summary

Feature	Button	Description
Show Histogram	<code>pushbutton8</code>	Opens a side-by-side view of original and filtered image + their histograms
Histogram Equalization	<code>pushbutton10</code>	Improves image contrast by redistributing intensities
Contrast Stretching	<code>pushbutton11</code>	Stretches pixel intensities to new min/max from <code>edit1</code> , <code>edit2</code>
Min/Max Values	<code>edit1</code> , <code>edit2</code>	User-input for desired new intensity range

## ▼ 4 Noise Cancellation

### `pushbutton29_Callback` – Apply Noise Cancellation Filter

```
function pushbutton29_Callback(hObject, eventdata, handles)
```

 Triggered when the "Apply Noise Cancellation" button is clicked.



## ✓ 1. Check for Image Availability

```
if ~isfield(handles, 'currentImage') || isempty(handles.currentImage)
    error('Please load an image first.', 'No Image Found');
return;
end
```

✓ Ensures that an image is loaded. If not, shows error and exits the function.

## 📁 2. Get Selected Filter from `popupmenu6`

```
filterList = get(handles.popupmenu6, 'String');
selectedFilter = filterList{get(handles.popupmenu6, 'Value')};
```

- Gets the list of all filter names in the dropdown.
- Reads the selected filter based on the current value (index).

## 🧠 3. Use the Latest Image (Filtered or Original)

```
try
    if isfield(handles, 'filteredImage') && ~isempty(handles.filteredImage)
        img = handles.filteredImage;
    else
        img = handles.currentImage;
    end

    originalImg = img; % Store a copy for histogram comparison
```

✓ Prefers using a previously filtered image to allow chaining operations. Stores the input as `originalImg` for later histogram display.

## 🌈 4. Grayscale Conversion (If RGB)

```
if size(img, 3) == 3
    img = rgb2gray(img);
    isRGB = true;
```

```

else
    isRGB = false;
end

```

✓ Many filters work best on grayscale images, so it checks if the image is RGB and converts it if needed.

Also stores a flag `isRGB` to convert back later if necessary.

## 5. Apply Selected Filter

```

switch selectedFilter
case 'Min Filter'
    filteredImg = ordfilt2(img, 1, ones(handles.kernelSize));

```

● **Min Filter:** Uses `ordfilt2` to get the **minimum value** in the neighborhood.

```

case 'Max Filter'
    filteredImg = ordfilt2(img, handles.kernelSize^2, ones(handles.kernelSize));

```

● **Max Filter:** Gets the **maximum value** (last in sorted window).

```

case 'Mean Filter'
    h = fspecial('average', handles.kernelSize);
    filteredImg = imfilter(img, h);

```

● **Mean Filter:** Uses averaging kernel and applies it with `imfilter`.

```

case 'Median Filter'
    filteredImg = medfilt2(img, [handles.kernelSize handles.kernelSize]);

```

● **Median Filter:** Removes salt-and-pepper noise.

```

matlab
Copy code
case 'Midpoint Filter'
    minImg = ordfilt2(img, 1, ones(handles.kernelSize));

```

```
maxImg = ordfilt2(img, handles.kernelSize^2, ones(handles.kernelSize));
filteredImg = (double(minImg) + double(maxImg)) / 2;
filteredImg = uint8(filteredImg);
```

🟢 **Midpoint Filter:** Averages the min and max of the neighborhood.

---

## 6. Restore RGB Format If Needed

```
if isRGB
    filteredImg = cat(3, filteredImg, filteredImg, filteredImg);
end
```

📌 If the original image was RGB, rebuild a 3-channel image from the grayscale output.

---

## 7. Display Original and Filtered Image

```
axes(handles.axes1);
imshow(handles.currentImage);
title('Original Image');


axes(handles.axes2);
imshow(filteredImg);
title([selectedFilter ' Result']);
```

 Shows original on `axes1` and filtered image on `axes2`.

---

## 8. Save the Filtered Image

```
handles.filteredImage = filteredImg;
guidata(hObject, handles);
```

 Stores the result in `handles` for future steps (like histogram, further filtering, etc.).

---

## 9. Create Histogram Comparison Figure

```
hFig = figure('Name', 'Histogram Comparison', 'NumberTitle', 'off', 'Position', [100 100 1000 800]);
```

 Creates a new window titled "Histogram Comparison".

## 10. Display Original Image and Histogram

```
subplot(2,2,1);  
if size(originalImg, 3) == 3  
    imshow(originalImg);  
    title('Original Color Image');  
  
    subplot(2,2,3);  
    imhist(originalImg(:, :, 1)); hold on;  
    imhist(originalImg(:, :, 2));  
    imhist(originalImg(:, :, 3)); hold off;  
    title('Original RGB Histograms');  
    legend('Red', 'Green', 'Blue');
```

 If RGB:

- Top-left: image
- Bottom-left: histogram of R, G, B channels

```
else  
    imshow(originalImg);  
    title('Original Grayscale Image');  
  
    subplot(2,2,3);  
    imhist(originalImg);  
    title('Original Histogram');  
end
```

☐ If grayscale, just show image and single histogram.


## 11. Display Processed Image and Histogram

```

subplot(2,2,2);
imshow(filteredImg);
title([selectedFilter ' Result']);

subplot(2,2,4);
if isRGB
    imhist(filteredImg(:,:,1)); hold on;
    imhist(filteredImg(:,:,2));
    imhist(filteredImg(:,:,3)); hold off;
    title('Processed RGB Histograms');
    legend('Red','Green','Blue');

```

 If processed image is RGB, show each channel's histogram.

```

else
    imhist(filteredImg);
    title('Processed Histogram');
end

```

☐ If grayscale, single histogram.




## 12. Add Title to Histogram Window

```

annotation(hFig, 'textbox', [0.3 0.95 0.4 0.05], 'String', ...
    ['Histogram Comparison: ' selectedFilter ' (Kernel: ' num2str(handles.kernelSize) 'x' num2str(handles.kernelSize) ')'], ...
    'EdgeColor', 'none', 'HorizontalAlignment', 'center', ...
    'FontSize', 12, 'FontWeight', 'bold');

```


 Adds a title at the top of the histogram window showing the filter name and kernel size.

## 13. Error Catching

```

catch e
    errorDlg(['Error applying ' selectedFilter ': ' e.message], 'Filter Error');
end

```


 Shows an error message if anything in the `try` block fails.

---

## `popupmenu6` – Noise Filter Selection

### Selection Callback


```
function popupmenu6_Callback(hObject, eventdata, handles)
```

 Called when the user selects a new option. Currently, it's empty, so it does nothing unless filled.

---

### Create Function (Style Setup)

```
function popupmenu6_CreateFcn(hObject, eventdata, handles)
if ispc && isequal(get(hObject,'BackgroundColor'), get(0,'defaultUicontrolBackgroundColor'))
    set(hObject,'BackgroundColor','white');
end
```

 Ensures the background is white on Windows platforms for consistent UI look.

---

## Summary Table

Component	Role
<code>pushbutton29</code>	Applies selected noise-canceling filter
<code>popupmenu6</code>	Lets the user choose filter (Min, Max, Mean, etc.)
<code>handles.kernelSize</code>	Defines size of neighborhood window
Filters Supported	Min, Max, Mean, Median, Midpoint
Histograms	Compared between original and filtered images
RGB Handling	Converts to grayscale for filtering, restores later

## ▼ Adding Noise

### Group 1: Salt & Pepper Noise

## UI Controls

- Button: `pushbutton18`
- Inputs: `edit7` (PS = Salt Probability), `edit8` (PP = Pepper Probability)

## Callback: `pushbutton18_Callback`

```
% --- Executes on button press in pushbutton18 (Salt & Pepper Noise).  
function pushbutton18_Callback(hObject, eventdata, handles)
```

Called when Salt & Pepper button is clicked.

```
ps = str2double(get(handles.edit7, 'String'));  
pp = str2double(get(handles.edit8, 'String'));
```

Reads salt ( `ps` ) and pepper ( `pp` ) probabilities from the edit boxes.

```
if isnan(ps) || isnan(pp) || ps < 0 || pp < 0 || (ps+pp) > 1  
    errordlg('Please enter valid probabilities (0 <= PS,PP <= 1, PS+PP <= 1)', 'Invalid Input');  
    return;  
end
```

Validates input values: must be between 0 and 1 and their sum  $\leq 1$ .

```
if ~isfield(handles, 'currentImage') || isempty(handles.currentImage)  
    errordlg('Please load an image first!', 'No Image');  
    return;  
end
```

Checks image existence.

```
if isfield(handles, 'filteredImage') && ~isempty(handles.filteredImage)  
    img = handles.filteredImage;  
else  
    img = handles.currentImage;  
end
```

Chooses the image to add noise to.

```
noisy_img = imnoise(img, 'salt & pepper', ps+pp);
```

Adds salt & pepper noise with total probability `ps + pp`.

```
axes(handles.axes1); imshow(handles.currentImage); title('Original Image');  
axes(handles.axes2); imshow(noisy_img); title(['Salt & Pepper Noise (PS = ' num2str(ps) ', PP=' num2str(pp) ')']);
```

Displays original and noisy images.

```
handles.filteredImage = noisy_img;  
guidata(hObject, handles);
```

Stores result for next processing step.



### `edit7` / `edit8` – Salt & Pepper Inputs

Both validate that values are between 0 and 1:

```
validateInput(hObject, 0, 1, false);
```



## Group 2: Uniform Noise



### UI Controls

- Button: `pushbutton19`
- Inputs: `edit9` (a), `edit10` (b), `edit11` (P%)



### Callback: `pushbutton19_Callback`

```
a = str2double(get(handles.edit9, 'String'));  
b = str2double(get(handles.edit10, 'String'));  
P = str2double(get(handles.edit11, 'String'))/100;
```

Reads noise bounds `a`, `b` and percentage `P`.



```
if isnan(a) || isnan(b) || isnan(P) || b <= a || P <= 0 || P > 1
```

Validates inputs ( $a < b$ ,  $0 < P \leq 1$ ).

```
noise = a + (b-a)*rand(rows, cols, ch);  
noisy_img = double(img) + P*noise;
```

Generates uniform noise and adds it scaled by `P`.

```
noisy_img = max(0, min(255, noisy_img)); noisy_img = uint8(noisy_img);
```

Clips and converts result to `uint8`.



## Edits for Uniform Noise

Each has `validateInput` with correct bounds:

- `edit9`:  $a \rightarrow [-255, 255]$
- `edit10`:  $b \rightarrow [-255, 255]$
- `edit11`:  $P \rightarrow [0-100]$



## Group 3: Gaussian Noise



### UI Controls

- Button: `pushbutton20`
- Inputs: `edit12` ( $\sigma$ ), `edit13` ( $\mu$ ), `edit14` (P%)



### Callback: `pushbutton20_Callback`

```
seg = str2double(get(handles.edit12, 'String'));  
m = str2double(get(handles.edit13, 'String'));  
P = str2double(get(handles.edit14, 'String'))/100;
```

Reads standard deviation ( $\sigma$ ), mean ( $\mu$ ), and percentage.

```
matlab  
Copycode
```

```
noise = m + seg*randn(rows, cols, ch);  
noisy_img = double(img) + P*noise;
```

Adds Gaussian noise scaled by `P`.

```
matlab  
Copycode  
noisy_img = max(0, min(255, noisy_img)); noisy_img = uint8(noisy_img);
```



## Gaussian Inputs

- `edit12` :  $\sigma \rightarrow [0-100]$
- `edit13` :  $\mu \rightarrow [-255, 255]$
- `edit14` :  $P \rightarrow [0-100]$



## Group 4: Rayleigh Noise



### UI Controls

- Button: `pushbutton21`
- Inputs: `edit20` (a), `edit19` (b)



### Callback: `pushbutton21_Callback`

```
a = str2double(get(handles.edit20, 'String'));  
b = str2double(get(handles.edit19, 'String'));
```

```
noise = a + (-b*log(1 - rand(rows, cols, ch))).^0.5;  
noisy_img = double(img) + noise;
```

Generates Rayleigh noise using its formula.



## Rayleigh Inputs

- `edit20` :  $a \rightarrow [0-255]$
- `edit19` :  $b \rightarrow [0.01-255]$

## Group 5: Exponential Noise

### UI Controls

- Button: `pushbutton22`
- Inputs: `edit17` (a), `edit18` (b)

### Callback: `pushbutton22_Callback`

```
a = str2double(get(handles.edit17, 'String'));  
b = str2double(get(handles.edit18, 'String'));
```

```
noise = (-1/a)*log(1 - rand(rows, cols, ch));  
noisy_img = double(img) + b*noise;
```

Applies exponential noise.



### Exponential Inputs

- `edit17` : a → [0.01–100]
- `edit18` : b → [0–255]

## Group 6: Gamma Noise

### UI Controls

- Button: `pushbutton24`
- Inputs: `edit21` (a), `edit22` (b)

### Callback: `pushbutton24_Callback`

```
a = str2double(get(handles.edit21, 'String'));  
b = str2double(get(handles.edit22, 'String'));
```

```
if exist('gamrnd', 'file')  
    noise = gamrnd(a, b, rows, cols, ch);  
else
```

```

noise = zeros(rows, cols, ch);
for k = 1:a
    noise = noise - b*log(1 - rand(rows, cols, ch));
end
end

```

Generates gamma noise with fallback if `gamrnd()` doesn't exist.



## Gamma Inputs

- `edit21` :  $a \rightarrow [0-100]$
- `edit22` :  $b \rightarrow [0-255]$



## Summary Table

Noise Type	Button	Inputs	Core Formula / Method
Salt & Pepper	pushbutton18	edit7, edit8	<code>imnoise(..., 'salt &amp; pepper', ps + pp)</code>
Uniform	pushbutton19	edit9–edit11	<code>a + (b-a)*rand</code>
Gaussian	pushbutton20	edit12–edit14	<code><math>\mu + \sigma * \text{randn}</math></code>
Rayleigh	pushbutton21	edit20, edit19	<code><math>a + \text{sqrt}(-b * \log(1 - \text{rand}))</math></code>
Exponential	pushbutton22	edit17, edit18	<code><math>-1/a * \log(1 - \text{rand})</math></code>
Gamma	pushbutton24	edit21, edit22	<code>gamrnd(a, b)</code> or fallback loop using <code>log(1-u)</code>

## ▼ 6 Point Detection & Sharpening



### `pushbutton28_Callback` — Apply Point Operation

```

% --- Executes on button press in pushbutton28 (Apply Point Operation)
function pushbutton28_Callback(hObject, eventdata, handles)

```

📌 This function runs when the user clicks the "Apply" button to perform either Point Detection or Point Sharpening.

## 1. Check if Image is Loaded

```
try
    if ~isfield(handles, 'currentImage') || isempty(handles.currentImage)
        errorDlg('Please load an image first!', 'No Image');
        return;
    end
```

✓ If no image is loaded into the GUI, show an error and cancel processing.

## 2. Get Selected Operation from Dropdown

```
operations = get(handles.popupmenu7, 'String');
selectedOp = operations{get(handles.popupmenu7, 'Value')};
```

- Retrieves the list of options from `popupmenu7`
- Gets the selected string (e.g., `'Point Detection'` or `'Point Sharpening'` )

## 3. Convert to Grayscale (if needed)

```
if size(handles.currentImage, 3) == 3
    img = rgb2gray(handles.currentImage);
else
    img = handles.currentImage;
end
```

 Ensures the image is single-channel (grayscale) for filtering operations.

## 4. Apply Selected Operation

```
switch selectedOp
```

Starts a switch-case block based on the chosen point operation.

## Case 1: Point Detection

```
case 'Point Detection'
    h = [1 1 1; 1 -8 1; 1 1 1]; % Laplacian kernel
```

This is a **Laplacian kernel** used for edge/point detection. It enhances regions with rapid intensity changes.

```
filtered = imfilter(double(img), h, 'same');
```

Applies the kernel filter to the image using `imfilter`. Converts image to `double` for accurate computation.

```
result = abs(filtered); % Get absolute values
```

✓ Removes negative values from the result (Laplacian can produce both positive and negative edges).

```
result = uint8(255 * mat2gray(result)); % Normalize to 0-255
```

- `mat2gray` scales values between 0–1
- Then multiplied by 255 and converted to `uint8`

## 🟡 Case 2: Point Sharpening

```
case 'Point Sharpening'
    blurred = imgaussfilt(img, 2);
```

🟠 Uses **Gaussian blur** to smooth the image.

```
mask = img - blurred;
```

Subtracts the blurred image from the original to isolate **edges and details** (this is the "mask").

```
result = img + mask; % Add the mask back to original
```

Adds the mask back to sharpen the image = Unsharp Masking.

```
result = uint8(min(max(result, 0), 255)); % Clamp to 0-255
```

Clips any overflows and converts to `uint8`.

## 5. Display Original and Result

```
axes(handles.axes1);  
imshow(handles.currentImage);  
title('Original Image');
```


 Shows the original image in `axes1`.

```
axes(handles.axes2);  
imshow(result);  
title(selectedOp);
```

 Shows the result of point detection or sharpening in `axes2`, with title.


## 6. Save Result for Next Steps

```
handles.filteredImage = result;  
guidata(hObject, handles);
```

 Stores the processed image for further processing (e.g., histogram, noise canceling).

## 7. Error Handling

```
catch ME  
    errordlg(['Error in ' selectedOp ': ' ME.message], 'Processing Error');  
end
```

 If something goes wrong, display a detailed error dialog.

 `popupmenu7_Callback` and `CreateFcn`

This function runs when the user changes the dropdown. It's not used actively here (the `pushbutton28` handles the selection).

```
function popupmenu7_CreateFcn(hObject, eventdata, handles)
    if ispc && isequal(get(hObject,'BackgroundColor'), get(0,'defaultUicontrolBackgroundColor'))
        set(hObject,'BackgroundColor','white');
    end
end
```

📌 Ensures the dropdown background color looks correct on Windows systems.

📌 **Summary Table**

Feature	UI Element	Operation
Point Detection	<code>pushbutton28</code> + 'Point Detection' in <code>popupmenu7</code>	Uses Laplacian kernel <code>[-8 center]</code> to highlight point features
Point Sharpening	<code>pushbutton28</code> + 'Point Sharpening' in <code>popupmenu7</code>	Applies Unsharp Masking (original + details from Gaussian difference)

▼ **7 Line Detection & Sharpening**

✅ **Functional Buttons and UI Elements**


Feature	Function	Related UI
General Apply	<code>pushbutton27</code>	<code>popupmenu8</code>
Horizontal Line Detection	<code>pushbutton31</code>	
Vertical Line Detection	<code>pushbutton32</code>	
Diagonal Left Line Detection	<code>pushbutton33</code>	
Diagonal Right Line Detection	<code>pushbutton34</code>	

**`pushbutton27_Callback` — Main Line Detection & Sharpening**

```
% --- Executes on button press in pushbutton27.
```



```
function pushbutton27_Callback(hObject, eventdata, handles)
```

 Triggered when user clicks the "Apply" button for line operations.

## ✓ 1. Image Existence Check

```
try
    if ~isfield(handles, 'currentImage') || isempty(handles.currentImage)
        errordlg('Please load an image first!', 'No Image');
        return;
    end
```

Checks if any image has been loaded. If not, an error is shown and function exits.

## 2. Get User Selection from Dropdown

```
operations = get(handles.popupmenu8, 'String');
selectedOp = operations{get(handles.popupmenu8, 'Value')};
```

- Retrieves list of options in `popupmenu8`.
- Gets the selected operation name.

## 3. Convert to Grayscale (if necessary)

```
if size(handles.currentImage, 3) == 3
    img = rgb2gray(handles.currentImage);
else
    img = handles.currentImage;
end
```

✓ Ensures the image is grayscale (most edge and line detectors operate on 2D images).

## 4. Apply Operation Based on Selection

```
switch selectedOp
```

### ● Case: Line Detection (Sobel)

```
case 'Line Detection (Sobel)'  
    result = edge(img, 'sobel', 'horizontal');
```

Uses MATLAB's `edge` function with the Sobel operator in the horizontal direction.

### ● Case: Line Detection (Roberts)

```
case 'Line Detection (Roberts)'  
    result = edge(img, 'roberts', 'horizontal');
```

Applies the Roberts cross operator for line edge detection, defaulted to horizontal.

### ● Case: Line Sharpening

```
case 'Line Sharpening'  
    blurred = imgaussfilt(img, 1);  
    mask = img - blurred;  
    result = img + 1.5*mask;  
    result = uint8(min(max(result, 0), 255));
```


- Applies **unsharp masking**:
  - Blurs the image.
  - Subtracts blur from original to form a detail-enhancing mask.
  - Adds the mask with a multiplier (1.5x) to increase sharpness.
  - Ensures pixel values are clamped between 0 and 255.



## 5. Display Original and Processed Images

```
axes(handles.axes1);
imshow(handles.currentImage);
title('Original Image');

axes(handles.axes2);
imshow(result);
title([selectedOp ' Result']);
```

 Shows original and processed results in separate axes.

## 6. Save the Result for Further Use

```
handles.filteredImage = result;
guidata(hObject, handles);
```


## 7. Error Catching

```
catch ME
    errordlg(['Error in ' selectedOp ': ' ME.message], 'Processing Error');
end
```

Catches and shows an error dialog if something fails in the try block.

## **popupmenu8\_Callback** — Dropdown Selection Handling

```
% --- Executes on selection change in popupmenu8 line detect and sha
rpening
function popupmenu8_Callback(hObject, eventdata, handles)
    set([handles.pushbutton31, handles.pushbutton32, handles.pushbutton33, handles.pushbutton34], 'Visible', 'on');
    guidata(hObject, handles);
```

 When user selects a different operation, this ensures the four **direction buttons** remain visible for optional directional detection.

```
function popupmenu8_CreateFcn(hObject, eventdata, handles)
    if ispc && isequal(get(hObject,'BackgroundColor'), get(0,'defaultUicontrolBackgroundColor'))
        set(hObject,'BackgroundColor','white');
    end
end
```

Ensures proper UI background appearance for Windows users.

## Directional Line Detection

Each button ( `pushbutton31-34` ) uses a common helper function called `applyLineOperation` , which takes a direction code.

### `pushbutton31` → Horizontal (H)

```
function pushbutton31_Callback(hObject, eventdata, handles)
    applyLineOperation(handles, 'H');
```

### `pushbutton32` → Vertical (V)

```
function pushbutton32_Callback(hObject, eventdata, handles)
    applyLineOperation(handles, 'V');
```

### `pushbutton33` → Diagonal Left (DL)


```
function pushbutton33_Callback(hObject, eventdata, handles)
    applyLineOperation(handles, 'DL');
```

### `pushbutton34` → Diagonal Right (DR)

```
function pushbutton34_Callback(hObject, eventdata, handles)
    applyLineOperation(handles, 'DR');
```

### `applyLineOperation(handles, direction)`


```
matlab
Copy code
function applyLineOperation(handles, direction)
```

 This is a helper function that performs direction-specific line detection or sharpening.

## Main Steps

### 1. Image Check & Preparation

```
matlab
Copy code
if ~isfield(handles, 'currentImage') || isempty(handles.currentImage)
    errorDlg(...); return;
end
```

 Validates the image exists.

```
matlab
Copy code
operations = get(handles.popupmenu8, 'String');
selectedOp = operations{get(handles.popupmenu8, 'Value')};
img = rgb2gray_if_needed(handles.currentImage); % Ensures grays
cale
img = double(img);
```

### 2. Select Kernel Based on Operation & Direction

```
matlab
Copy code
switch selectedOp
    case 'Line Detection (Sobel)'
        % Sobel directional kernels
        switch direction
```

```

        case 'H': [-1 -2 -1; 0 0 0; 1 2 1]
        case 'V': [-1 0 1; -2 0 2; -1 0 1]
        case 'DL': [0 1 2; -1 0 1; -2 -1 0]
        case 'DR': [-2 -1 0; -1 0 1; 0 1 2]
    end

    case 'Line Detection (Roberts)'
        % Roberts 2×2 directional kernels
        switch direction
            case 'H': [1 0; 0 -1]
            case 'V': [0 1; -1 0]
            case 'DL': [0 -1; 1 0]
            case 'DR': [-1 0; 0 1]
        end
    end

    case 'Line Sharpening'
        % Directional sharpening
        switch direction
            case 'H': [0 -1 0; 0 3 0; 0 -1 0]
            case 'V': [0 0 0; -1 3 -1; 0 0 0]
            case 'DL': [-1 0 0; 0 3 0; 0 0 -1]
            case 'DR': [0 0 -1; 0 3 0; -1 0 0]
        end
    end
end
result = imfilter(img, kernel);

```

### 3. Post-Processing & Display

```

matlab
Copy code
result = im2uint8(mat2gray(result)); % Normalize and convert
imshow result in axes2 with title
save to handles.filteredImage

```

### 4. Error Handling

```

matlab
Copy code
catch ME
    errordlg(['Error in ' selectedOp ': ' ME.message], 'Processing Error');
end

```

## ✓ Summary Table

Operation	Direction	Kernel Type	Purpose
<b>Sobel</b>	H/V/DL/DR	3×3	Edge/line detection
<b>Roberts</b>	H/V/DL/DR	2×2	Simple diagonal edge detection
<b>Sharpening</b>	H/V/DL/DR	3×3	Directional detail enhancement

## ✓ Summary Table

Feature	Trigger	Core Technique	Description
<b>Line Detection (Sobel)</b>	<code>pushbutton27</code> + dropdown	<code>edge(img, 'sobel')</code>	Detects edges in horizontal direction
<b>Line Detection (Roberts)</b>	<code>pushbutton27</code> + dropdown	<code>edge(img, 'roberts')</code>	Uses Roberts operator for fine edges
<b>Line Sharpening</b>	<code>pushbutton27</code> + dropdown	Unsharp Masking (1.5×)	Enhances edges with boosted difference mask
<b>Directional Detection (H/V/DL/DR)</b>	<code>pushbutton31–34</code>	Custom kernel + <code>applyLineOperation()</code>	Detects lines in specific directions

## ▼ 8 Transformation

📌 Functional Buttons and Inputs:

Transformation	Button	Input(s)
<b>Negative</b>	<code>pushbutton37</code>	—
<b>Log Transform</b>	<code>pushbutton40</code>	—
<b>Gamma</b>	<code>pushbutton41</code>	<code>edit23</code>

## Group 1: Negative Transformation

### Button: `pushbutton37`

```
matlab
Copy code
function pushbutton37_Callback(hObject, eventdata, handles)
```

Triggered when the **Negative Transform** button is pressed.

### Check Image Exists

```
matlab
Copy code
if ~isfield(handles, 'currentImage') || isempty(handles.currentImage)
    errorDlg('Please load an image first!', 'No Image Loaded');
    return;
end
```

### Select Image to Use

```
matlab
Copy code
if isfield(handles, 'filteredImage') && ~isempty(handles.filteredImage)
    img = handles.filteredImage;
else
    img = handles.currentImage;
```



```
end
```

✓ Uses filtered image if available; otherwise uses the original.

## Apply Negative Transformation

```
matlab  
Copy code  
negative = 255 - img;
```

Inverts pixel values to create a **photographic negative**.

## Display

```
matlab  
Copy code  
axes(handles.axes1); imshow(handles.currentImage); title('Original Image');  
axes(handles.axes2); imshow(negative); title('Negative Transform');
```

## Store Result

```
matlab  
Copy code  
handles.filteredImage = negative;  
guidata(hObject, handles);
```

## Error Handling

```
matlab  
Copy code  
catch ME
```

```
errorDlg(['Error in negative transformation: ' ME.message], 'Processing Error');  
end
```

## Group 2: Logarithmic Transformation

 Button: `pushbutton40`

```
matlab  
Copy code  
function pushbutton40_Callback(hObject, eventdata, handles)
```

Triggered when **Log Transform** is clicked.

### Image Check and Selection

Same logic as above:

```
matlab  
Copy code  
if ~isfield(handles, 'currentImage') || isempty(handles.currentImage)  
    errorDlg(...); return;  
end  
  
img = (filteredImage if exists) or currentImage;
```

### Normalize and Apply Log Transform

```
matlab  
Copy code  
img = im2double(img); % Convert to range [0,1]  
c = 1 / log(1 + max(img(:)));
```

```
logImg = c * log(1 + img);
```

- `log(1 + img)` enhances darker regions.
- `c` scales the image to stay in [0, 1].

## Convert to uint8 and Display

```
matlab
Copy code
transformed = im2uint8(logImg);
axes(handles.axes2); imshow(transformed); title('Log Transform');
```

## Store Result

```
matlab
Copy code
handles.filteredImage = transformed;
guidata(hObject, handles);
```

## Error Handling

```
matlab
Copy code
catch ME
    errorDlg(['Error in log transformation: ' ME.message], 'Processing Error');
end
```

## Group 3: Gamma Correction

 Button: `pushbutton41`

## Input Box: edit23

```
matlab
Copy code
function pushbutton41_Callback(hObject, eventdata, handles)
```

## Image Check

```
matlab
Copy code
if ~isfield(handles, 'currentImage') || isempty(handles.currentImage)
    errorDlg(...); return;
end
```

## Read and Validate Gamma Value

```
matlab
Copy code
gammaStr = get(handles.edit23, 'String');
gamma = str2double(gammaStr);

if isnan(gamma) || gamma <= 0
    errorDlg(...); set(handles.edit23, 'String', '1.0'); return;
end
```

## Apply Gamma Transformation

```
matlab
Copy code
img = im2double(handles.currentImage);
gammaImg = img.^gamma;
```

```
filtered = im2uint8(gammalmg);
```

✓ Applies the power-law transformation to enhance either bright or dark areas.

---

## Display and Store

```
matlab
Copy code
axes(handles.axes1); imshow(handles.currentImage); title(...);
axes(handles.axes2); imshow(filtered); title(...);
handles.filteredImage = filtered;
guidata(hObject, handles);
```

## ✗ Error Handling

```
matlab
Copy code
catch ME
    errordlg(['Error in gamma transformation: ' ME.message], 'Processing
Error');
end
```

## **edit23\_Callback** — Live Gamma Preview

```
matlab
Copy code
function edit23_Callback(hObject, eventdata, handles)
```

## Get and Validate Input

```
matlab
Copy code
gammaStr = get(hObject, 'String');
gamma = str2double(gammaStr);

if isnan(gamma) || gamma <= 0
    errordlg(...); set(hObject, 'String', '1.0'); return;
end
```

## Preview on Small Image

```
matlab
Copy code
if isfield(handles, 'currentImage') && ~isempty(handles.currentImage)
    smallImg = imresize(handles.currentImage, 0.2);
    previewImg = im2uint8(im2double(smallImg).^gamma);
    axes(handles.axes2); imshow(previewImg); title(...);
end
```

## **edit23\_CreateFcn**

```
matlab
Copy code
function edit23_CreateFcn(hObject, eventdata, handles)
    set(hObject,'BackgroundColor','white');
    set(hObject, 'String', '1.0'); % Default gamma
end
```

## Summary Table

Transformation	Function	Description
<b>Negative</b>	<code>pushbutton37</code>	Inverts pixel values: <code>255 - img</code>

<b>Log Transform</b>	<code>pushbutton40</code>	Enhances dark pixels: <code>c * log(1 + img)</code>
<b>Gamma</b>	<code>pushbutton41</code> + <code>edit23</code>	Nonlinear power correction: <code>img ^ γ</code>

## ▼ **9** Frequency Domain Filter

### GUI Elements

- **popupmenu10**: Dropdown menu for selecting the filter type:
  - 'Ideal Low Pass'
  - 'Ideal High Pass'
  - 'Butterworth Low Pass'
  - 'Butterworth High Pass'
  - 'Gaussian Low Pass'
  - 'Gaussian High Pass'
- **edit26**: User input for cutoff frequency `D0`.
- **edit27**: User input for Butterworth filter order `n`.
- **pushbutton50**: Executes the selected filter on the image.

### `pushbutton50_Callback` : Apply Frequency Filter

```
matlab
Copy code
function pushbutton50_Callback(hObject, eventdata, handles)
```

Triggered when the user clicks the "Apply Frequency Filter" button.

```
matlab
Copy code
if ~isfield(handles, 'currentImage') || isempty(handles.currentImage)
    errorDlg('Please load an image first!', 'No Image');
    return;
end
```

Checks if an image is loaded.

```
matlab
Copy code
D0 = str2double(get(handles.edit26, 'String'));
n = str2double(get(handles.edit27, 'String'));
filterTypes = get(handles.popupmenu10, 'String');
filterType = get(handles.popupmenu10, 'Value');
selectedFilterName = filterTypes{filterType};
```

Retrieves the cutoff frequency `D0`, filter order `n`, and selected filter type from the GUI.

```
matlab
Copy code
if isnan(D0) || D0 <= 0
    errordlg('Please enter a valid positive D0 value!', 'Invalid Parameter');
    return;
end

if (filterType == 3 || filterType == 4) && (isnan(n) || n <= 0)
    errordlg('Please enter a valid positive Butterworth order!', 'Invalid Parameter');
    return;
end
```

Validates the inputs: `D0` must be positive. `n` is required only for Butterworth filters.

```
matlab
Copy code
if size(handles.currentImage, 3) == 3
    img = rgb2gray(handles.currentImage);
else
    img = handles.currentImage;
```



```
end
```

Converts image to grayscale for frequency filtering.

```
matlab
Copy code
switch filterType
    case 1
        filtered = idealFilter(img, D0, 'low');
    case 2
        filtered = idealFilter(img, D0, 'high');
    case 3
        filtered = butterworthFilter(img, D0, n, 'low');
    case 4
        filtered = butterworthFilter(img, D0, n, 'high');
    case 5
        filtered = gaussianFilter(img, D0, 'low');
    case 6
        filtered = gaussianFilter(img, D0, 'high');
end
```

Applies the appropriate filter by calling a helper function.

```
matlab
Copy code
axes(handles.axes1); imshow(handles.currentImage); title('Original Image');
axes(handles.axes2); imshow(filtered); title([selectedFilterName ' Filter']);
handles.filteredImage = filtered;
guidata(hObject, handles);
```

Displays the original and filtered images and updates `filteredImage`.

## Helper Functions



## idealFilter

matlab

Copy code

```
function output = idealFilter(img, D0, type)
```

Creates a binary mask: pass if distance from center  $\leq$  `D0`.

matlab

Copy code

```
H = double(D <= D0); % low-pass
```

```
H = double(D > D0); % high-pass
```



## butterworthFilter

matlab

Copy code

```
function output = butterworthFilter(img, D0, n, type)
```

Smooth transition based on cutoff `D0` and order `n`:

matlab

Copy code

```
H = 1 ./ (1 + (D./D0).^(2*n)); % low-pass
```

```
H = 1 ./ (1 + (D0./D).^(2*n)); % high-pass
```



## gaussianFilter

matlab

Copy code

```
function output = gaussianFilter(img, D0, type)
```

Smoothest transition:

```
matlab
Copy code
H = exp(-(D.^2)./(2*D0^2));    % low-pass
H = 1 - exp(-(D.^2)./(2*D0^2)); % high-pass
```



### applyFrequencyFilter

```
matlab
Copy code
function output = applyFrequencyFilter(img, H)
```

Core operation shared by all filters:

- Converts image to frequency domain via `fft2`
- Applies filter mask `H`
- Returns inverse FFT and normalizes to 0–1

```
matlab
Copy code
F = fftshift(fft2(img));
G = H .* F;
output = real(ifft2(ifftshift(G)));
output = mat2gray(output);
```

## ✓ Summary

Filter Type	Uses <code>n</code> ?	Function Called
Ideal Low/High Pass	✗	<code>idealFilter</code>
Butterworth Low/High	✓	<code>butterworthFilter</code>
Gaussian Low/High	✗	<code>gaussianFilter</code>

## ▼ 10 Fourier Transformation

### **pushbutton45\_Callback** – Fourier Transform

```
matlab
Copy code
function pushbutton45_Callback(hObject, eventdata, handles)
```

Triggered when the "Fourier Transform" button is clicked.

```
matlab
Copy code
if ~isfield(handles, 'currentImage') || isempty(handles.currentImage)
    errorDlg('Please load an image first!', 'No Image');
    return;
end
```

✓ Checks if an image is loaded. If not, shows an error and exits.

```
matlab
Copy code
if size(handles.currentImage, 3) == 3
    img = rgb2gray(handles.currentImage);
else
    img = handles.currentImage;
end
```

 Converts the image to grayscale if it's in color (3-channel RGB).

```
matlab
Copy code
f_img = fft2(double(img));           % Compute 2D Fourier Transform
fshift = fftshift(f_img);           % Shift zero-frequency component to cent
er
```

```
magnitude_spectrum = mat2gray(log(1 + abs(fshift))); % Log scale for visibility
```

📌 Applies the **Fast Fourier Transform**, centers it, and prepares the magnitude spectrum for display using log scaling.

```
matlab  
Copy code  
handles.fourierData = fshift; % Store for inverse use
```

💾 Saves the frequency domain data for future use.

```
matlab  
Copy code  
axes(handles.axes2);  
imshow(magnitude_spectrum, []);  
colormap(handles.axes2, gray);  
colorbar(handles.axes2);  
title('Fourier Transform (Magnitude Spectrum)');
```

🎨 Displays the frequency spectrum in `axes2`.

```
matlab  
Copy code  
guidata(hObject, handles);
```

↻ Updates the GUI state.

## 🔴 `pushbutton46_Callback` – Inverse Fourier Transform

```
matlab  
Copy code
```

```
function pushbutton46_Callback(hObject, eventdata, handles)
```

Called when "Inverse Fourier Transform" is clicked.

```
matlab
Copy code
if ~isfield(handles, 'fourierData') || isempty(handles.fourierData)
    errorDlg('Please perform Fourier Transform first!', 'No Fourier Data');
    return;
end
```

⚠ Verifies that Fourier data exists before proceeding.

```
matlab
Copy code
f_ishift = ifftshift(handles.fourierData); % Unshift the frequency image
img_back = ifft2(f_ishift);                % Apply inverse FFT
```


↺ Reverses the frequency shift and performs the **inverse FFT** to reconstruct the image.

```
matlab
Copy code
axes(handles.axes2);
imshow(img_back, []);
title('Inverse Fourier Transform (Reconstructed Image)');
colorbar(handles.axes2, 'off');
```

🖥 Displays the reconstructed image from frequency domain.

```
matlab
Copy code
handles.reconstructedImage = img_back;
```

```
guidata(hObject, handles);
```

 Stores and updates the GUI state.

## Summary

Button	Function Name	Description
pushbutton45	<code>pushbutton45_Callback</code>	Computes and shows the Fourier magnitude spectrum
pushbutton46	<code>pushbutton46_Callback</code>	Reconstructs the image using inverse Fourier Transform

## ▼ Brightness

### Brightness Adjustment Functionalities

#### Components:

- **Addition** → `pushbutton52`
- **Multiplication** → `pushbutton53`
- **Subtraction** → `pushbutton54`
- **Division** → `pushbutton55`
- **Brightness Value Input** → `edit28`

#### `edit28_Callback` & `edit28_CreateFcn`

```
matlab
Copy code
function edit28_Callback(hObject, eventdata, handles)
value = str2double(get(hObject, 'String'));
if isnan(value)
    errorDlg('Please enter a valid number!', 'Invalid Input');
    set(hObject, 'String', '10');
end
handles.brightnessValue = value;
```

```
guidata(hObject, handles);
```

- Retrieves and validates the numeric input.
- Stores it in `handles.brightnessValue`.

matlab

Copy code

```
function edit28_CreateFcn(hObject, eventdata, handles)
set(hObject, 'BackgroundColor', 'white');
set(hObject, 'String', '10');
```

- Initializes the brightness edit box with default value 10.

### ◆ `pushbutton52_Callback` – Brightness Addition

matlab

Copy code

```
function pushbutton52_Callback(hObject, eventdata, handles)
```

- Adds the value from `edit28` to each pixel.
- Converts to double to avoid overflow during calculation.
- Uses `min(..., 255)` to clamp values.

### ◆ `pushbutton53_Callback` – Brightness Multiplication

matlab

Copy code

```
function pushbutton53_Callback(hObject, eventdata, handles)
```

- Multiplies each pixel by the value from `edit28`.
- Input must be positive.



- Clamps the result to 255 to avoid overflow.

### ◆ `pushbutton54_Callback` – Brightness Subtraction

matlab

Copy code

```
function pushbutton54_Callback(hObject, eventdata, handles)
```

- Subtracts the value from each pixel.
- Uses `max(..., 0)` to avoid underflow.

### ◆ `pushbutton55_Callback` – Brightness Division

matlab

Copy code

```
function pushbutton55_Callback(hObject, eventdata, handles)
```

- Divides each pixel by the value from `edit28`.
- Input must be positive and non-zero.
- Uses `max(..., 0)` to clamp any potential negatives due to rounding.

## 🧠 Shared Logic Summary

In all four operations:

- If a filtered image exists ( `handles.filteredImage` ), it is used instead of the original.
- Results are displayed in `axes2`.
- The original is shown in `axes1`.
- Output is saved back to `handles.filteredImage`.

## ▼ 1 2 Conversion

### ☐ Binary Conversion

- **Button:** `pushbutton56`
- **Input Field (Threshold):** `edit29`

## ◆ Code Explanation

```
matlab
Copy code
function pushbutton56_Callback(hObject, eventdata, handles)
```

Triggered when the user clicks the **Binary Conversion** button.

```
matlab
Copy code
if ~isfield(handles, 'currentImage') || isempty(handles.currentImage)
    errorDlg('Please load an image first!', 'No Image');
    return;
end
```

Validates that an image is loaded.

```
matlab
Copy code
threshold = str2double(get(handles.edit29, 'String'));
if isnan(threshold) || threshold < 0 || threshold > 255
    errorDlg('Threshold must be between 0-255!', 'Invalid Threshold');
    return;
end
```

Reads and validates the threshold input from `edit29`.

```
matlab
Copy code
if size(handles.currentImage, 3) == 3
    grayImg = rgb2gray(handles.currentImage);
else
```

```
grayImg = handles.currentImage;  
end
```

Converts the image to grayscale if it's RGB.

```
matlab  
Copy code  
handles.processedImage = imbinarize(grayImg, threshold/255);
```

Applies **binary thresholding** (0 to 1 scale for `imbinarize` ).

```
matlab  
Copy code  
axes(handles.axes2);  
imshow(handles.processedImage);  
title(['Binary Image (Threshold: ' num2str(threshold) ')']);
```

Displays the binary image in `axes2` .

```
matlab  
Copy code  
guidata(hObject, handles);
```

Saves changes to the GUI state.

## Grayscale Conversion

- **Button:** `pushbutton58`
- **Input Field (Method):** `edit30`

## Code Explanation

```
matlab  
Copy code
```

```
function pushbutton58_Callback(hObject, eventdata, handles)
```

Triggered on pressing the **Grayscale Conversion** button.

```
matlab
Copy code
if ~isfield(handles, 'currentImage') || isempty(handles.currentImage)
    errorDlg('Please load an image first!', 'No Image');
    return;
end
```

Checks if an image is loaded.

```
matlab
Copy code
method = round(str2double(get(handles.edit30, 'String')));
if isnan(method) || method < 1 || method > 5
    errorDlg('Method must be 1-5!', 'Invalid Method');
    return;
end
```

Reads and validates the grayscale method from `edit30` .

```
matlab
Copy code
if size(handles.currentImage, 3) == 3
    switch method
        case 1 % Average
            grayImg = mean(handles.currentImage, 3);
        case 2 % Weighted (Luminance)
            weights = [0.2989, 0.5870, 0.1140];
            grayImg = handles.currentImage(:,:,1)*weights(1) + ...
                handles.currentImage(:,:,2)*weights(2) + ...
                handles.currentImage(:,:,3)*weights(3);
        case 3 % Red channel
```

```

        grayImg = handles.currentImage(:,:,1);
    case 4 % Green channel
        grayImg = handles.currentImage(:,:,2);
    case 5 % Blue channel
        grayImg = handles.currentImage(:,:,3);
    end
    handles.processedImage = uint8(grayImg);
else
    handles.processedImage = handles.currentImage;
end

```

Applies the selected grayscale method:

- **1:** Average all RGB channels.
- **2:** Use standard luminance weights.
- **3-5:** Use individual color channels.

```

matlab
Copy code
axes(handles.axes2);
imshow(handles.processedImage);
methodNames = {'Average', 'Luminance', 'Red Channel', 'Green Channel', 'Blue Channel'};
title(['Grayscale (' methodNames{method} ')']);

```

Displays the result with a dynamic title.

```

matlab
Copy code
guidata(hObject, handles);

```

Updates the GUI state.

## Input Field Validators

### **edit29** (Binary Threshold)

matlab

Copy code

```
function edit29_Callback(hObject, eventdata, handles)
val = str2double(get(hObject, 'String'));
if isnan(val) || val < 0 || val > 255
    errorDlg('Threshold must be 0-255!', 'Invalid Input');
    set(hObject, 'String', '127');
end
```

### **edit30** (Grayscale Method)

matlab

Copy code

```
function edit30_Callback(hObject, eventdata, handles)
val = round(str2double(get(hObject, 'String')));
if isnan(val) || val < 1 || val > 5
    errorDlg('Method must be 1-5!', 'Invalid Input');
    set(hObject, 'String', '1');
end
```

## ▼ **1 3** Browse & Save image

### ◆ **1. Browse Image** — **pushbutton42**

matlab

Copy code

```
function pushbutton42_Callback(hObject, eventdata, handles)
[filename, pathname] = uigetfile({'*.jpg;*.png;*.bmp;*.tif;*.tiff', 'Image Files'}, 'Select an Image');
if isequal(filename, 0)
    return; % User cancelled
end

try
```

```

img = imread(fullfile(pathname, filename)); % Read image
handles.currentImage = img; % Store it in handles
axes(handles.axes1); imshow(img); % Show on axes1
title('Original Image');
guidata(hObject, handles); % Save handles changes
catch e
    errorDlg(['Error loading image: ' e.message], 'Image Load Error');
end
end
end

```

### Explanation:

- Opens a file dialog for image selection.
- Reads the image and stores it as `handles.currentImage`.
- Displays the image in `axes1` with the title "Original Image".
- `guidata` is called to store the updated handles.
- If there's an error (e.g., unreadable file), it shows an error dialog.

## 2. Save Image — `pushbutton43`

```

matlab
Copy code
function pushbutton43_Callback(hObject, eventdata, handles)
    if ~isfield(handles, 'filteredImage') || isempty(handles.filteredImage)
        errorDlg('No filtered image available to save. Please apply a filter fir
st.', 'Nothing to Save');
        return;
    end

    filteredImg = handles.filteredImage;
    defaultName = ['filtered_' datestr(now, 'yyyymmdd_HHMMSS') '.png'];

    [filename, pathname] = uiputfile(...
        {'*.png','PNG files (*.png)'; ...
        '*.jpg','JPEG files (*.jpg)'; ...

```

```

        '*.tif','TIFF files (*.tif)'; ...
        '*.*','All Files (*.*)'}, ...
        'Save Filtered Image As', ...
        defaultName);

if isequal(filename, 0) || isequal(pathname, 0)
    return; % User cancelled
end

try
    [~, ~, ext] = fileparts(filename);
    switch lower(ext)
        case '.png'
            imwrite(filteredImg, fullfile(pathname, filename), 'png');
        case '.jpg'
            imwrite(filteredImg, fullfile(pathname, filename), 'jpg', 'Quality',
90);
        case '.tif'
            imwrite(filteredImg, fullfile(pathname, filename), 'tif');
        otherwise
            imwrite(filteredImg, fullfile(pathname, [filename '.png']), 'pn
g'); % default to PNG
    end
    msgbox(['Image successfully saved to: ' fullfile(pathname, filename)
e]), 'Save Complete');
catch e
    errorDlg(['Error saving image: ' e.message], 'Save Error');
end
end

```

### **Explanation:**

- Checks if a filtered image exists to save.
- Creates a default filename with timestamp.
- Opens a save file dialog ( `uiputfile` ) with image format options.
- Uses `imwrite()` to save the image in the selected format.



- If extension is missing or unknown, defaults to PNG.
- Shows confirmation or error dialogs.

### ◆ 3. Edit Field for Filename (optional) — `edit24`

```
matlab
Copy code
function edit24_Callback(hObject, eventdata, handles)
% Called when user types in edit24 — Not actively used in save logic
end

function edit24_CreateFcn(hObject, eventdata, handles)
    if ispc && isequal(get(hObject,'BackgroundColor'), get(0,'defaultUicontrolBackgroundColor'))
        set(hObject,'BackgroundColor','white');
    end
end
```

#### 📌 Explanation:

- `edit24` appears to be unused in the saving logic.
- Standard setup to make sure it has a white background on Windows.
- Might be used for manual filename input in future versions.